

2.4 Main Page of Configuration

Save Parameters



3

Recall Stored Parameters



Set All Defaults



Start Configuration



1

End Configuration



4

Abort Configuration



Version Information



Save Parameters -

The parameter settings will be saved permanently.

Recall Stored Parameters -

Replace the current parameters by the parameters you saved last time.

Set All Defaults -

Set all the parameters to the factory default settings.

Abort Configuration -

Terminate current programming status.

Version Information -

Display the decoder version information and date code.

4.3 Output Characters Parameters

A> Select Terminator

<CR+LF>



None



CR



2

LF



Space



HT(TAB)



STX-ETX

